

Diagnosis code chart

Code	Symptoms
13	Incorrect pick-up coil input signal
15	Incorrect engine cooling water temperature sensor input signal
18	Incorrect throttle position sensor input signal
19	Incorrect battery positive voltage
23	Incorrect intake air temperature sensor input signal
28	Incorrect shift position switch
29	Incorrect intake air pressure sensor input signal (out of normal operating range)
33 ~ 44	Microcomputer processing information
(33)	Ignition timing is being slightly corrected (when starting a cold engine)
(37)	Intake passage air leakage
(44)	Engine stop switch control operating